
10/511602



10/511602







FIG.3



SPEED CONTROL BRAKE RELEASE MECHANICAL LnR POSITION HOLDING CONTROL LbR ⋖ \circ ACTUATE MECHANICAL BRAKE LzR PERFORM POSITION HOLDING CONTROL ONLY WHEN STOPPING ROTATING BODY AFTER DECELERATION (VALID FOR SET PERIOD OF TIME) F1G.4 0 Z Θ LzL POSITION HOLDING CONTROL \circ LbL ⋖ BRAKE RELEASE MECHANICAL Lh SPEED CONTROL

10/511602





10/511602




FIG.8





FIG.9



10/511602





FIG.11



ENCODER 38 INVERTER F1G.12 37 20 ω ref ഗ

FIG. 13




FIG.14

